

Pristine® FILTRATION STRAW

CARE INSTRUCTIONS

1 Twist upper portion of Straw to expose the filter. Soak Filter for 30 secs to 1 min prior to 1st use only. This is to prime the filter.



2 Do not wash the filter with soap and water.



3 When not in use, separate the upper portion to expose the filter and allow to air dry. Once completely dry, store Straw in the resealable pouch provided.




4 When Straw is close to capacity it will become more difficult to draw water. How long Straw lasts depends on the quality of water being filtered.




INSTRUCTIONS FOR USE


1 Remove cap, place bottom of Straw directly in water, and drink.




2 To increase Straw length, twist lower half of Straw and pull to release.




3 With bottom of Straw immersed in water, push and pull lower half of Straw to pump.



4 Connect tubing to the bottom of Straw to use with a water bag system or increase reach to water supply.



5 Straw can be threaded onto any standard pop bottle. Once attached, activate the pump to transfer filtered water into clean container.



SAFE DRINKING WATER. ANYWHERE. EVERY TIME.
Converts to a pump! Order your replacement Filtration Straw [here](#) >

Pristine®
pristine.ca